



NOTE:

1. PROVIDE MEGALUG JOINT RESTRAINT ON ALL MJ FITTINGS.
2. PROVIDE 14-GAUGE TRACER WIRE AND BRING ALONG SIDE OF HYDRANT BARREL AND TEST FOR CONTINUITY. SEE PLAN 381R FOR VALVE BOX TRACER WIRE.
3. PROVIDE MUELLER RESILIENT SEAT OR CLOW RESILIENT WEDGE GATE VALVES W/ THE STUFFING BOX FLANGED TO THE BONNET USING STAINLESS STEEL BOLTS AND NUTS. VALVES WITH BOLTS WHICH THREAD DIRECTLY INTO THE VALVE BODY ARE NOT ACCEPTED.
4. PROVIDE 8" WATER LINE AND FITTINGS WHEN LENGTH TO HYDRANT EXCEEDS 50-FEET. ALSO, PROVIDE ONE (1) ADDITIONAL VALVE ON THE SUPPLY LINE A DISTANCE OF 5' FROM THE HYDRANT, AND NOT WITHIN THE CURB AND GUTTER