



NOTE:

1. PROVIDE MEGALUG JOINT RESTRAINT ON ALL MJ FITTINGS.
2. PROVIDE 14-GAUGE TRACER WIRE AND BRING ALONG SIDE OF HYDRANT BARREL AND TEST FOR CONTINUITY. SEE PLAN 381R FOR VALVE BOX TRACER WIRE.