



- 1. ANCHOR BOLTS SUPPLIED WITH POLE. INSTALL PER MANUFACTURER'S INSTRUCTIONS.
- 2. BOND GROUND CONDUCTOR TO POLE.
- SEAL CONDUIT TO PREVENT WATER INFILTRATION.
- 4. PROVIDE SPARE CONDUIT 36" BEYOND LAST POLE ON CIRCUIT, AND CAP FOR FUTURE EXTENSION.

